

**UK Adhesive Recommendation for EarthWerks Glue Down | Dryback**

Supplier	Recommended adhesive	Notch Trowel
<b>Bostik</b>	Bostik's Best	A2
	Bostik Power Elastic	A2
	Nibofloor 800	A2
<b>F-Ball</b>	F44	A2
	F46	A1
	F48 plus	A2
<b>Henkel</b>	Thomsit K 188E	A2
	Thomsit K188 S	A2
<b>Mapei</b>	Ultrabond Eco 4 LVT	A2
	Ultrabond Eco V4 SP	A2
	Ultrabond Eco 360	A2
	Ultrabond Eco VS90 Plus	A2
<b>PCI</b>	UKL 302	
	PKL326	
<b>Schönox</b>	<b>Schönox DUROCOLL</b> (fibre reinforced, strong dispersiopl adhesive)	A1 / A2
	<b>Schönox PU 900</b> (Solvent free 2 component PU adhesive)	A2
<b>Stauf</b>	Stauf D 50 EC1 plus	A2
	Stauf D 37 EC1	A2
	Stauf R 105 EC1 plus	A2
<b>Uzin</b>	Uzin KE 2000S	A2 (A1)
	KE 66E	A2 (A1)
	Sigan Elements	Rolls
<b>Wakol</b>	Wakol D 3307	A2
	Wakol D 3320	A2
	Wakol D 3360	A2
<b>Wulff</b>	WULFF Ultra-Strong	A2
	WULFF Supra-Strong	A2
	WULFF Multi-Strong	A2

**Please follow also to our separate LVT - Glue Down installation guideline.**

Equivalent adhesives may be used - please follow the instructions of the respective adhesive supplier.